

TerraWave's enclosures are intended for indoor OR outdoor use and are commonly used in harsh environments. These enclosures protect WLAN equipment from damage caused by inclement weather and tampering. Proper mounting of the enclosure is essential in ensuring safety and reliability of your network. Below is a simple guide demonstrating the step by step installation process utilizing mounting flanges and a polycarbonate enclosure.



Mounting Flange Kit

### **Mounting Kit Includes:**

- Mounting Flanges (2)
- Mounting Bolts (4)

### **Additional Components Needed:**

- Polycarbonate Enclosure
- Phillips Screwdriver

### **Installation Instructions**

1. Place mounting flange on the back of the enclosure (Figure 1). The square pegs on the back of the enclosure will fit into the square recesses on the flange, exposing the brass insert.
2. Using the bolts provided, secure the flange to the top and bottom of the enclosure (Figure 2). Tighten, but do not over torque, the bolts using a Phillips screwdriver. **No power tools should be used.**
3. Once both flanges are installed on the back of the enclosure (Figure 3), it is ready to be easily mounted to a flat surface.



Placement of Mounting Flange  
Figure 1



Secure Mounting Flange  
Figure 2



Finished Enclosure  
Figure 3